




LOW VOLTAGE RESS LI-ION BATTERY USERS GUIDE



End User Documentation

Rev 1.0

Jun-10-2023

**WARNING:** Explosion, Electrocution, Or Fire Hazard

- ☑ A battery can present a risk of electric shock, burns from high short circuit current, fire, or explosion.
- ☑ Observe proper precautions.
- ☑ Ensure the cables are properly sized.
- ☑ Ensure clearance requirements are strictly enforced around the batteries.
- ☑ Ensure the area around the batteries is well ventilated and clean of debris.
- ☑ Always use insulated tools. Avoid dropping tools onto batteries or other electrical parts.
- ☑ If a battery must be removed, always remove the grounded terminal from the battery first. Make sure all devices are disconnected.
- ☑ All devices must be disconnected when update the BMS software.
- ☑ DO NOT short the battery terminals.
- ☑ DO NOT incinerate, crush, or disassemble.
- ☑ DO NOT reverse connections (polarity) from charger to battery.
- ☑ DO NOT operate battery beyond published voltage and current limits.

**IMPORTANT**

- ☑ When installing batteries, leave adequate clearance between batteries.
- ☑ When replacing batteries, use the same part number of batteries.
- ☑ Avoid any fall or collision during the installation process.
- ☑ Do not remove the battery components. The maintenance of the battery should be carried out by a professional engineer.
- ☑ Do not expose the Li-ion battery to heat in excess of 55°C during operation, 60 °C in storage;
- ☑ The SOC is 50% when shipped from factory, it needs to be recharged in time for long time storage.

LOW VOLTAGE RESS BATTERY

This series li-ion batteries are designed for the residential energy storage market (RESS) which combines safe and reliable LiFePO₄ prismatic cells with RESS dedicated BMS to guarantee high reliability, safety, and scalability when used with different inverter.

This series include 4 models configuration to adapt to the different capacity inverter.

51.2V100Ah (5.12KWH) ,

51.2V200Ah (100A),

51.2V200Ah (150A),

51.2V200Ah (200A),


This document is intended for use by anyone required to install and operate ~~AC~~ & { rack type Li-ion batteries. Be sure to review this manual carefully to identify any potential safety risks before proceeding.


The owner must be familiar with all the features of this product before proceeding.

Failure to install or use this product as instructed can result in damage to the product that may not be covered under the limited warranty.

Product Introduction

The RESS batteries are shown in below figures.






LEDs indicator
(ALM, RUN, SOC)

ADD


Breaker

ON/OFF button

Water proof cover



Communication port



87654321

RS485 PIN MAP

RJ45 PIN	Description
1	RS485_B
2	RS485_A
3,4,5,6,7,8	NC

CAN PIN MAP

RJ45 PIN	Description
1,2,3,4,5,6	NC
7	CAN_H
8	CAN_L

LINK-IN/OUT PIN MAP







RJ45 PIN	Description
1,2,3,4,5,6	NC
7	RS485-2_A
8	RS485-2_B

ADD Switch



ADD	1#	2#	3#	4#	Remark
0	OFF	OFF	OFF	OFF	Pack 0
1	ON	OFF	OFF	OFF	Pack 1 Master Battery
2	OFF	ON	OFF	OFF	Pack 2
3	ON	ON	OFF	OFF	Pack 3
4	OFF	OFF	ON	OFF	Pack 4
5	ON	OFF	ON	OFF	Pack 5
6	OFF	ON	ON	OFF	Pack 6
7	ON	ON	ON	OFF	Pack 7
8	OFF	OFF	OFF	ON	Pack 8
9	ON	OFF	OFF	ON	Pack 9
10	OFF	ON	OFF	ON	Pack 10
11	ON	ON	OFF	ON	Pack 11
12	OFF	OFF	ON	ON	Pack 12
13	ON	OFF	ON	ON	Pack 13
14	OFF	ON	ON	ON	Pack 14
15	ON	ON	ON	ON	Pack 15

LED Indicator Description

Status	Nominal Warning Protection	RUN 	ALM 	SOC    				Description
Shut down	Dormancy	OFF	OFF	OFF	OFF	OFF	OFF	
Standby	Nominal	Flash 1	OFF	Follow module capacity				Standby
	Warning	Flash 1	Flash 3					Module at low voltage
Charge	Nominal	ON	OFF	Follow module capacity				
	Warning	ON	Flash 3					
	Over-charge Protection	ON	OFF	ON	ON	ON	ON	LED turn to standby if no power supply
	Temperature, over-current, Failure protection	OFF	ON	OFF	OFF	OFF	OFF	Stop charging
Discharge	Nominal	Flash 3	OFF	Follow module capacity				
	Warning	Flash 3	Flash 3					
	Under voltage Protection	OFF	OFF	OFF	OFF	OFF	OFF	Stop discharging
	Temperature, over-current, short circuit, failure protection	OFF	ON	OFF	OFF	OFF	OFF	Stop discharging
Failure		OFF	ON	OFF	OFF	OFF	OFF	Stop charging and discharging

Note:

Flash 1: light 0.25s/off 3.75s

Flash 2: light 0.5s / off 0.5s

Flash 3: light 0.5s / off 1.5s

ON/OFF Button



OFF mode

During in transport, BMS ON/OFF button is at OFF status. it will turn off the BMS power supply.



ON mode

By press ON/OFF button to active BMS to enter into working mode, if the MCB is also ON, the battery voltage will can be measured by terminal.

Even if the button is at ON mode, The BMS will enter into dormancy mode after 24 hours when there are no charge, no discharge and no communication. it can be activated again by charge or communication or repress ON/OFF button.

History Record

The BMS can restore 500 logs about historical alarm / protection data, the logs can be read by PC software.

Parameters

Model	RES20010K
Nominal Voltage [V]	51.2
Nominal Capacity [Ah]	200
Total Energy [Wh]	10240
Dimension (W*D*H, mm)	520*165*865
Weight [Kg]	96
Max. Charging Current [A]	200
Max. Discharging Current [A]	200
Pulse Discharge Current	210A @ 10min 220A @ 10s
Charging Voltage [V]	55.2~57.6
End of Discharge Voltage [V]	44.8 (Backup Application) / 48 (Cycle Application)
Operation Humidity	0~95% RH (No condensing)
Operating Temperature Range	Standard Product: Charge: 0 ~ +55°C; Discharge: -20 ~ +55°C With Optional Heater: Charge / Discharge: -30 ~ +55°C
Cycle Life ⁽¹⁾	>6000
Designed Calendar Life	10 Years
Communication interface	RS485, CAN
Protection	Over voltage , Low voltage, Over current, Over Temperature, Low Temperature, Short circuit
Parallel Support ⁽²⁾	Yes, Max. 15 Sets
Series Support	Not support

TRANSPORTATION AND STORAGE

Transportation requirement

The product passes the certifications of the UN38.3 (UN38.3: Section 38.3 of the sixth Revised Edition of the Recommendations on the Transport of Dangerous Goods, Manual of Tests and Criteria) and SN/T 0370.2-2009 (Part 2: Performance Test of the Rules for the Inspection of Packaging for Exporting Dangerous Goods). This product belongs to class 9 dangerous goods.

The SOC is 50% when shipped from factory.

The product can be delivered to the site directly and transported by land and water. The packing case must be secured for transportation, compliant with related national standards,

and printed with marks such as anti-collision and moisture prevention. Dispose of waste ESMs in strict accordance with local laws and regulations.

Protect the packing case with the product from the following situations:

- Being dampened by rains, snows, or falling into water
- Falling or mechanical impact
- Being upside-down or tilted

Storage

The rack type Li-ion battery can be stored in an environment with temperatures between -40°C and +60°C and between 10% and 90% relative humidity, non-condensing. For long storage periods at 25°C, charge the battery every 6 months. For temperatures above 40°C, charge the battery every quarter.

Do not store the Li-ion battery at temperatures above 60°C.

Keep away from heat sources (such as a heater)

Communication with different inverter

RESS li-ion battery BMS support to do communication with below inverters.


This chapter mainly introduce the communication cable connection and BMS software configuration.

SN	Inverter Brand	Adaption Series	Communication
1	Victron	CCGX- VE-CAN	CAN
2	SMA	SUNNY ISLAND Series	CAN
3	Megarevo	REVO Series	CAN
8	MUST	Solar Inverter 2KW-5.5KW	CAN
4	Voltronic	Axpert Series	RS485
5	Growatt	SPF *** TL, ES, Series.	RS485
6	OPTI	SP5000 Handy Plus	RS485
7	DEYE	SUN-3K/3.6K-SG04LP1	RS485
9	INHENERGY	HI-**-SL Series	RS485
10	Afore	HNS3000-6000HS	RS485
11	Phocos	Any-Grid PSW-H	RS485

Note: The list of inverter will renew by the BMS software update, the newest inverter list will shown on BMS PC software.

Communication cable

The accessories communication cable is standard T-568B CAT5-e cable. it can be used for battery-battery internal communication and inverter CAN (Victron), RS485 (Growatt, DEYE, INHENERGY), for other brand inverter, it needs to modify communication cable according to PINOUT of inverter.



BMS RS485 and CAN Port, Major inverter BMS Port.


PIN	BMS		CAN				RS485					
	RS485	CAN	Victron	SMA	Megarevo	MUST	Growatt	Voltronic	DEYE	Afore	Phocos	INHENERGY
1	485_B	NC	NET-C/V-	Sync1-reserved	/	485_B	485_B	/	485_B	Meter 485A	232_RX	485_B
2	485_A	NC	NET-S/V+	CAN_GND	/	485_A	485_A	/	485_A	Meter 485B	232_TX	486_A
3	NC	NC	NET-C/V-	SYNC_H	/	GND	NC	485_B	/	BAT 485A	485_B	GND_S
4	NC	NC	NC	CAN_H	CAN_H	/	NC	/	CAN_H	BAT CANH	+12Vdc	CAN_H
5	NC	NC	NC	CAN_L	CAN_L	CAN_L	NC	485_A	CAN_L	BAT CANL	485_A	CAN_L
6	NC	NC	NET-S/V+	SYNC_L	485_GND	CAN_H	NC	/	485_GND	BAT 485B	CAN_H	NTC.BAT
7	NC	CAN-H	CAN-H	Sync7-Reserved	485_A	/	NC	/	485_A	CTU	CAN_L	WAKE-
8	NC	CAN-L	CAN-L	Sync8-Reserved	485_B	/	NC	/	485_B	CTN	GND	WAKE+

System cable connection

- Step 1. Make sure the battery breaker is in off condition. Connect the power cable to inverter. Make sure the screws are tight.
- Step 2. Connect the communication cable.
- Step 3. Set the battery module ID by ADD. **The master battery which do communication with inverter ADD must be 1.**
- Step 4. Make sure the inverter had be installed correctly.
- Step 5. Press ON/OFF button to active the battery BMS and connect battery to PC by BMS PC software, select inverter protocol on BMS (detail operation refer to user manual)
- Step 6. Turn on battery breaker and the inverter will be activated, set the inverter (battery type and protocol).
- Step 7. If the communication between BMS and inverter is nominal, the SOC, temperature information in PC and inverter display will be totally same.
- Step 8. **Charge the batteries fully in first use.**

Note:


- For 1pcs 5KWH battery and 10KWH-100A, it max support 5KVA inverter or the real load power consumption is less than 5KW.
- For 1pcs 10KWH-150A battery, it max support 8KVA inverter or the real load power consumption is less than 7KW.
- For 1pcs 10KWH-200A battery, it max support 10KVA inverter or the real load power consumption is less than 8KW.



Charging Batteries

The constant current (CC) charger is recommended strongly.

The charge voltage and current setting can refer to below table:



- If there are communication between battery and inverter, the BMS will automatic request charge and discharge parameters from inverter,
- If there are no communication between battery and inverter, setting charge and discharge parameters on inverter.

Recommended setting for 51.2V battery:

Equalized charging voltage: 56.0Vd

Float charging voltage: 53.9Vdc

Charge current: 0.5C


End of discharge voltage: 48Vdc

BMS PC Software Operation

1. Download BMS PC software and Unzip to a local folder.

http://120.27.63.138:8181/docs/bms_software/bms_pcsoftware


2. Connect battery LINK-IN port to computer by RS485 to USB equipment:



3. Check the battery ADD and make sure the ID=1



4. Double click “BMSTool.exe” to run BMS PC software.



Battery ADD

If RS485 to USB device is connected well, the serial port will be listed, otherwise, it needs to install USB driver.

3. Click “Connect”, the BMS detail information will be listed

The screenshot shows the BMSTool software interface. At the top, there is a 'Serial Port' section with a dropdown menu set to 'COM5', a 'Refresh' button, and a 'Connect' button. Below this, there are several tabs: 'RealTimeMonitoring', 'ParameterSetting', 'System Settings', 'Inverter Protocol Settings', 'Logs', and 'Help'. The 'RealTimeMonitoring' tab is active, displaying various battery parameters such as Pack Current, Pack Voltage, SOC, SOH, and Cell Voltage (mV). There are also sections for Temperature (C), Alarm Status, Protect Status, Fault Status, Equilibrium, and Switch Status. The 'Connect' button is highlighted with a red box, and a red arrow points to it from the text '3. Click “Connect”, the BMS detail information will be listed'.

BMSTool

RealTimeMonitoring | ParameterSetting | System Settings | Inverter Protocol Settings | Logs | Help

Serial Port: Port COM5, Baud Rate 9600, Interval (S) 0.5, Save

Buttons: 0, 1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 14, 15, Auto

Pack Information

Pack Current	0.0	A	Remain/Capacity	6.3	Ah
Pack Voltage	48.8	V	Full Capacity	30.0	Ah
SOC	21.0	%	Rated Capacity	30.0	Ah
SOH	100.0	%	Battery Cycle	1	

Temperature (C)

MaxTemp	29.0	2	Min Temp	28.4	3
Temp 1	28.9		Temp 4	28.5	
Temp 2	29.0		MOS Temp	29.2	
Temp 3	28.4		Env Temp	31.0	

Cell Voltage (mV)

Cell V1	3252	Cell V9	3251		
Cell V2	3233	Cell V10	3252		
Cell V3	3252	Cell V11	3251		
Cell V4	3251	Cell V12	3251		
Cell V5	3251	Cell V13	3251		
Cell V6	3251	Cell V14	3251		
Cell V7	3251	Cell V15	3250		
Cell V8	3252	Cell V16	0		
MaxVolt	3252	10	MinVolt	3233	2
VoltDif	19				

Alarm Status
No Alarm

Protect Status
No Protect

Fault Status
No Fault

Equilibrium

Cell V1	OFF	Cell V1	OFF
Cell V1	OFF	Cell V1	OFF
Cell V1	OFF	Cell V1	OFF
Cell V1	OFF	Cell V1	OFF
Cell V1	OFF	Cell V1	OFF
Cell V1	OFF	Cell V1	OFF
Cell V1	OFF	Cell V1	OFF
Cell V1	OFF	Cell V1	OFF

SwitchStatus

PACK STATU	STANDBY
CHG MOS	ON
DSG MOS	ON
LIMIT MOS	OFF
HEATING MOS	OFF
DRY CONN1	OFF
DRY CONN2	OFF
PRE MOS	OFF

Communication Normal Password Login LIMIT MOS Connect Disconnect Forced Shutdown

Battery information:
Total current, Total voltage,
SOC, SOH, Remain capacity,
Rated capacity, Cycle times.

Cells information:
Cell voltage

Alarm, Protection, Fault
information

Temperature information:
Cell temperature
Environment temperature
BMS temperature (MOS)

Note:

The Parameter setting change must be carried out by a professional engineer.

BMSTool

RealTimeMonitoring | ParameterSetting | System Settings | Inverter Protocol Settings | Logs | Help

Buttons: Clear, Deselect All, Write, Stop, Read, Clear, Restore

Communication protocol

Pack OV Alarm Protect

<input type="checkbox"/>	Pack OV Alarm (V)	
<input type="checkbox"/>	Pack OV Protect (V)	
<input type="checkbox"/>	Pack OVP Release (V)	
<input type="checkbox"/>	Pack OVP Delay Time (mS)	

Cell OV Alarm Protect

<input type="checkbox"/>	Cell OV Alarm (V)	
<input type="checkbox"/>	Cell OV Protect (V)	
<input type="checkbox"/>	Cell OVP Release (V)	
<input type="checkbox"/>	Cell OVP Delay Time (mS)	

Pack UV Alarm Protect

<input type="checkbox"/>	Pack UV Alarm (V)	
<input type="checkbox"/>	Pack UV Protect (V)	
<input type="checkbox"/>	Pack UVP Release (V)	
<input type="checkbox"/>	Pack UVP Delay Time (mS)	

Cell UV Alarm Protect

<input type="checkbox"/>	Cell UV Alarm (V)	
<input type="checkbox"/>	Cell UV Protect (V)	
<input type="checkbox"/>	Cell UVP Release (V)	
<input type="checkbox"/>	Cell UP Delay Time (mS)	

CHG OC Alarm Protect

<input type="checkbox"/>	CHG OC Alarm (A)	
<input type="checkbox"/>	CHG OC Protect (A)	
<input type="checkbox"/>	CHG OC Delay Time (mS)	

CHG OT Alarm Protect

<input type="checkbox"/>	CHG OT Alarm (°C)	
<input type="checkbox"/>	CHG OT Protect (°C)	
<input type="checkbox"/>	CHG OTP Release (°C)	

DSG OT Alarm Protect

<input type="checkbox"/>	DSG OT Alarm (°C)	
<input type="checkbox"/>	DSG OT Protect (°C)	
<input type="checkbox"/>	DSG OTP Release (°C)	

CHG UT Alarm Protect

<input type="checkbox"/>	CHG UT Alarm (°C)	
<input type="checkbox"/>	CHG UT Protect (°C)	
<input type="checkbox"/>	CHG UTP Release (°C)	

DSG OC Alarm Protect

<input type="checkbox"/>	DSG OC Alarm (A)	
<input type="checkbox"/>	DSG OC 1 Protect (A)	
<input type="checkbox"/>	DSG OC 1 Delay Time (mS)	
<input type="checkbox"/>	DSG OC 2 Protect (A)	
<input type="checkbox"/>	DSG OC 2 Delay Time (mS)	

DHG UT Alarm Protect

<input type="checkbox"/>	DHG UT Alarm (°C)	
<input type="checkbox"/>	DHG UT Protect (°C)	
<input type="checkbox"/>	DHG UTP Release (°C)	

MOS OT Alarm Protect

<input type="checkbox"/>	MOS OT Alarm (°C)	
<input type="checkbox"/>	MOS OT Protect (°C)	
<input type="checkbox"/>	MOS OTP Release (°C)	

ENV OT Alarm Protect

<input type="checkbox"/>	ENV OT Alarm (°C)	
<input type="checkbox"/>	ENV OT Protect (°C)	
<input type="checkbox"/>	ENV OTP Release (°C)	

ENV UT Alarm Protect

<input type="checkbox"/>	ENV UT Alarm (°C)	
<input type="checkbox"/>	ENV UT Protect (°C)	
<input type="checkbox"/>	ENV UTP Release (°C)	

Balance Threshold (mV)

<input type="checkbox"/>	Balance Δ Vcell (mV)	
--------------------------	-----------------------------	--

Sleep Vcell (V)

<input type="checkbox"/>	Delay Time (s)	
<input type="checkbox"/>	SCP Delay Time (uS)	
<input type="checkbox"/>	SOC Low Alarm (%)	

BMS Version

<input type="checkbox"/>	Model SN	
<input type="checkbox"/>	PACK SN	


2021-12-22 09:09:10

- 📄 Click “Read” to check currently loaded communication protocols.
- 📄 Select protocol by inverter brand and click “Write” to reload protocol.
- 📄 Click “Read” to check

The screenshot shows the BMSTool software interface with the 'Inverter Protocol Settings' tab selected. The interface includes a 'Clear' button at the top left. Below it, there are two main sections for protocol configuration. The left section is for RS485 Protocol, featuring a text input field, a 'Read' button, and a dropdown menu for 'Inverter Selection' with options: Growatt, Voltronic, PLY(DEYE,SMK), INHENERGY, and LUXPOWERTEK. The right section is for CAN Protocol, featuring a text input field, a 'Read' button, and a dropdown menu for 'Inverter Selection' with options: Victron-500Kbps, SMA, Megarevo, and MUST-500Kbps. Each section also has a 'Write' button. A status bar at the bottom left shows the date and time: 2021-12-22 09:09:10.

Annex A: Parallel Connection With Distribution BOX

Distribution box is optional for the situation which parallel over 3 batteries or 2~3 inverter in parallel.



Note:

- ☑ Ensure the cables are properly sized.
- ☑ The length fo cable should be same.